

Arc Cosine

`acos( a )`

Return the arc cosine of a.

Description

```
acos( a )
```

Return the arc cosine of a in radians.

Parameters

a	Value [-1 to +1]
---	------------------

Return value

arc cosine of a

Example usage

```
acos( 1 )
```

Returns 0.

From:
<https://doc.eze.io/> - ezeio documentation

Permanent link:
<https://doc.eze.io/ezeio2/expref/acos>

Last update: **2019-09-02 18:46**

