

Field value

f(fieldno)

Return the current value of a field.

Description

```
f( fieldno )
```

This function returns the current value of a given field.

Parameters

fieldno	Field number (1 through 90)
---------	-----------------------------

Return value

Returns the current value of the field.

Example usage

```
f(15)
```

From:
<https://doc.eze.io/> - **ezeio documentation**

Permanent link:
<https://doc.eze.io/ezeio2/expref/f>

Last update: **2019-09-02 18:49**

