

Minute

Minute()

Returns the current minute

Description

```
Minute()
```

Returns the current minute, 0-59.

Parameters

none

Return value

This function returns the current minute in the time zone set for the ezeio.

Example usage

```
Minute()
```

From:

<https://doc.eze.io/> - ezeio documentation

Permanent link:

<https://doc.eze.io/ezeio2/expref/minute>

Last update: **2019-09-02 18:52**

