

Square root

sqrt(a)

Returns the square root of a.

Description

```
sqrt( a )
```

Returns the square root of the value a.

Parameters

a	Value
---	-------

Return value

This function returns the square root of the value a.

Example usage

```
sqrt( 256 )
```

Returns 16.

From:

<https://doc.eze.io/> - ezeio documentation

Permanent link:

<https://doc.eze.io/ezeio2/expref/sqrt>

Last update: **2019-09-02 18:54**

