

GetField/GetFieldFloat

Get the value of a field

Description

`GetField(fieldno)`

`Float:GetFieldFloat(fieldno)`

Fetches the value of a field

Parameters

`fieldno` Which field to fetch

Return value

The value of the field. GetField will return the value rounded to the nearest integer.

Example usage

```
new x;
new Float:f;

x = GetField(4);
f = GetFieldFloat(4);

// x now holds the value of field 4, rounded to the nearest integer.
// f holds the value as a float.
```

From:

<https://doc.eze.io/> - ezeio documentation



Permanent link:

<https://doc.eze.io/ezeio2/scriptref/getfield>

Last update: **2020-09-16 23:17**