SetRegister

Set the value of a register

Description

```
SetRegister( deviceno, registerno, {Fixed,Float,_}:value, type=INT )
```

Directly sets the value of a register.

Parameters

deviceno	Device number (1-40)
registerno	Which register to set
value	The new value
type	One of INT, UINT, FLOAT or NULL

Return value

none

Example usage

```
    AllocateRegisters(3, 8);         // Allocate eight registers for device 3

    SetRegister(3, 1, 1234, INT);    // Set register 1 on device 3 to the value 1234
```

From:
https://doc.eze.io/ - **ezeio documentation**

Permanent link:
https://doc.eze.io/ezeio2/scriptref/setregister

Last update: **2020-08-14 20:19**