

SetTickInterval

Set the rate of the calls to @Tick.

Description

```
SetTickInterval( interval_ms )
```

This will change the rate of which the system triggers the @Tick event.

Parameters

interval_ms	The interval between events. 50-10000ms.
-------------	--

Return value

none

Example usage

```
main() {  
    SetTickInterval(100); // Set tick rate to 100ms  
}  
  
@Tick(uptime) {  
    // this code will be called ever 100ms  
}
```

From:

<https://doc.eze.io/> - ezeio documentation

Permanent link:

<https://doc.eze.io/ezeio2/scriptref/settickinterval>

Last update: **2019-09-02 21:42**

